

**INSTRUCTION AND MAINTENANCE MANUAL
FOR
TECHTROL FLOW INDICATING TOTALISE. ' TFIT '**

CONTENTS

1 Introduction & Working

2 Features

3 Specifications

4 Construction & Operation

4.1 Mechanical

4.2 Display

4.3 Keys

4.4 Terminal Details

5 Functional & Programming details

5.1 Run Mode

5.2 Program Mode

5.2.0 Menu 1 - Password configuration.

5.2.1 Menu 1 - Run time display configuration

**5.2.2 Menu 2 - Configure Level Range. Bottom offset, Level Unit,
Volume Unit and Tank number or Flow parameters if FLOW is selected.**

5.2.3 Menu 3 - Level Alarms set point programming .

5.2.4 Menu 4 - Relay programming

5.2.5 Menu 5 - Calibrate instrument for input

5.2.6 Menu 6 - Reset totalise.

5.2.7 Menu 7 - Volume strap table programming.

5.2.8 Menu 8 - Change Password

5.2.7 Menu 7 - Save programmed data.

6 Trouble shooting

We are glad to know that you are using a reliable ' Techtrol Product ". For proper and safe functioning of the same, we suggest you to go through this Manual carefully before installing our instrument.

INTRODUCTION & WORKING :

Techtrol Flow Indicating Totalise - TFIT is a unit to be used with FLOW Transmitters. Other versions are also available for Pressure, Temperature, Flow transmitters etc. T F I T works on 4 to 20 mA / 1 to 5 VDC input signal from transmitter. This analog input is converted to digital data by A to D Converter. A microprocessor then calibrates the input and controls the output functions of the Display & Relays as per configuration.

FEATURES :

- A** 16 X 2 Character Dot matrix backlit LCD Display.
- B** Two character tank identification.
- C** Level Display as per selected unit i.e. % / mm / cm / Mtr.
- D** Flow Display as per selected units i.e. M3/m , M3/H , Lt/m , Lt/s
- E** Volume calculations for Linear, Non-linear Tanks (Vessels) and display in % / Ltrs / KL / m³.
- F** Totalise flow unit in Ltrs , M3 , KL
- G** Four Level alarm generation and display [HH, H, L, LL]. Alarm set points are programmable.
- H** Relay outputs 4 nos. independently configurable on alarms or latching type ; set & reset.
- I** Programming is password protected
- J** RS232 or RS485 Communication available


SPECIFICATIONS :

CIRCUITRY	MICROCONTROLLER BASED
INPUT	4-20 mA / 1 to 5 Vdc analog
OUTPUT	Relay out put 4 nos. Contact rating 230VAC, 5A Configurable on one of the four level alarm or on latch mode set & reset Optional 1 RS232C / RS485 Output Protocol RTU Modbus 2 HART Communication Optional 3 4-20mA Max load 600E
DISPLAY	16 X 2 Character dot matrix LCD Display with backlit
PROGRAMMING	Using 5 function keys Mode,Next (Shift), Up (Increment), Down (Decrement), Enter
PROTECTION	Optical Isolation for Inputs/Outputs Lighting Protection using MOV's
SUPPLY	230VAC/110VAC 50Hz / 60Hz
ENCLOSURE	Panel mounting 96mm x 96mm x 150mm Protection IP41 Wall mounting 160mm x 160mm x 90mm Protection IP65


CONSTRUCTION & OPERATION :

MECHANICAL - TFIT is a panel mountable instrument (96mm x 96mm x 150mm) housed in an ABS plastic enclosure. A wall Mounting version is also available in glass polyester enclosure of the size of 160 x 160 x 90 mm.

DISPLAY - The front contains a 2 lines x 16 character dot matrix, LCD Display with Backlit.




Front Panel



KEYS - Five keys are provided for programming & to configure data. These are as follows,

- MODE** Mode Key - Press this key for programme / configure data.
- Next (Shift) Key** - In program mode this key is used to select next menu or shift right character while entering (modify) the data.
- Up (Increment) Key** - In programme mode this key is used to increment selected character data
- Down (Decrement) Key** - Not active
- ENTER** Enter Key - Key is used to enter parameter & go to run mode

Terminal Details on Rear -



FUNCTIONAL & PROGRAMMING DETAILS :

RUN MODE :

In run mode the data on display module can be viewed as in the front column.

Display line 1 -

Display line 2 - 1st 9 character field displays volume data, 1 character space & reaming field scrolls .Alarms , Relay 1 , Relay 2 , Relay 3 & Relay 4 on / off status.

LEVEL	T K : 0 1 L : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t A L : H H

LEVEL	T K : 0 1 L : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t R 1: O N

LEVEL	T K : 0 1 L : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t R 2: O F F

LEVEL	T K : 0 1 L : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t R 3: O N

LEVEL	T K : 0 1 L : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t R 4: O N

FLOW	F : 0 5 4 3 2 L t / s
	T : 5 0 0 0 0 2 3 4 2 8 L t

PROGRAM MODE :

DISTANCE	T K : 0 1 U : 0 2 0 0 0 mm
	V 0 5 0 0 0 0 L t A L : H H

MODE Press Mode Key for programming. The display show Menu1.

Menu 0 - This menu is used to enter password.

E n t e r P a s s _ w o r d
P a s W r d : _ _ _ _ _

ENTER Press ENTER key 7 times to go for programming
Or 7 Key combinations as selected
and go for Programming Menu 1

E n t e r P a s s _ w o r d
P a s W r d : * * * * * * *

ENTER No programming facility is available sorry?????

W r o n g _ P a s s w o r d
_ _ _ _ _

Press ENTER key to return to Run mode.

R E T U R N T O R U N
_ _ _ _ _

Menu 1 - This menu is used to select display parameters in Run mode

Press NEXT to display MENU - 2.

Press ENTER key to select Level display y/n

UP (INC) key is used to toggle y/n.

Press ENTER key to select Distance display y/n

UP (INC) key is used to toggle y/n.

Press ENTER key to select Flow display y/n

UP (INC) key is used to toggle y/n.

Press ENTER key to return to next MENU.

R	U	N	T	I	M	E	D	I	S	P	L	A	Y
E	n	a	b	l	e		D	I	s	p	a	b	l

R	U	N	T	I	M	E	D	I	S	P	L	A	Y
L	E	V	E	L		D	I	S	P	L	A	Y	y

R	U	N	T	I	M	E	D	I	S	P	L	A	Y
U	L	L	A	G	E		D	I	S	P	L	A	Y

R	U	N	T	I	M	E	D	I	S	P	L	A	Y
F	L	O	W		D	I	S	P	L	A	Y	Y	Y

Menu 2 - Configure Level Range, Bottom offset, Level Unit, Volume Unit and Tank number.

Press NEXT to Display MENU - 3.

Press ENTER to configure level range in mm.

NEXT (SHIFT) key is used to select digit

UP (INC) / DN (DEC) key is used to modify the digit.

Press ENTER key to configure Level bottom offset +ve or -ve for dead level or blanking distance of tank. NEXT & UP keys are used to select.

Press ENTER key to configure Level bottom offset in mm. NEXT & UP keys are used to select & modify the digit.

Press ENTER key to configure Level unit. UP (INC) key is used to toggle the units % / mm / cm / mtrs.

Press ENTER key to configure Volume unit. UP (INC) key is used to toggle the units % / Ltrs / KL / m³.

Press ENTER key to configure Tank No. NEXT, INC & DEC keys are used to select & modify the digits

Press ENTER key to return to next MENU.

C	o	n	f	i	g			
B	O	F	,	U	n	l	i	t	s	,	T	k	.	N	o	.

C	o	n	f	i	g
L	R	a	n	g	e	x	x	x	x	x	m	m	m

C	o	n	f	i	g
B	O	f	f	s	e	t	_	v	e	m	m	m	m

C	o	n	f	i	g
B	O	f	f	s	e	t	_	0	0	0	0	m	m

C	o	n	f	i	g
L	e	v	e	I	U	n	l	t		m	m	m	m

C	o	n	f	i	g
V	o	l	u	m	e	U	n	l	t		L	t	

C	o	n	f	i	g
T	a	n	k	N	o	:	X	X	X	X			

Menu 2 - Configure Flow parameters if Flow is selected.

Press NEXT to Display MENU - 3.

Press ENTER to configure level range in mm.

NEXT (SHIFT) key is used to select digit

UP (INC) key is used to modify the units.

Press ENTER key to configure maximum Flow.

C	o	n	f	i	g
R	a	n	g	e	u	n	l	t	T	y	o	w	

C	o	n	f	i	g
F	l	o	w		U	n	l	t	:	L	t	I	s

C	o	n	f	i	g
F	l	o	w		U	n	l	t	:	L	t	I	m

C	o	n	f	i	g
F	l	o	w		U	n	l	t	:	M	3	I	m

C	o	n	f	i	g
F	l	o	w		U	n	l	t	:	M	3	I	H

- ENTER** Press **ENTER** key to configure maximum Flow.
NEXT, INC & DEC keys are used to select & modify the digits
- ENTER** Press **ENTER** key to configure totalise Volume unit.
UP (INC) key is used to toggle the units
Ltrs / KL / m³.
- ENTER** Press **ENTER** key to configure slave address.
NEXT, INC & DEC keys are used to select & modify the digits
- ENTER** Press **ENTER** key to configure baud rate.
UP (INC) key is used to toggle the units
1200 / 2400 / 4800 / 9600

Config . . .	Flow
Flow R : XXXXX L t l s	
Config . . .	Flow
Total Unit	L t
Config . . .	Flow
Slave Add : 01	
Config . . .	Flow
Baud Rate : 120	

Menu 3 - Level Alarms set point values can be programmed using this menu.

- ENTER** Press NEXT key to display Menu 4.
- ENTER** Press **ENTER** key to configure Level alarm
HH alarm set point in mm .
NEXT (SHIFT) key is used to select digit
- ENTER** UP (INC) / DN (DEC) key is used to modify the digit.
- ENTER** Press **ENTER** key to configure Level alarm
H alarm set point in mm .NEXT INC & DEC keys are used to select & modify the digits.
- ENTER** Press **ENTER** key to configure Level alarm
L alarm set point in mm .NEXT INC & DEC keys are used to select & modify the digits.
- ENTER** Press **ENTER** key to configure Level alarm
LL alarm set point in mm .NEXT INC & DEC keys are used to select & modify the digits.
- ENTER** Press **ENTER** key to configure Level alarm
hysteresis in mm .NEXT INC & DEC keys are used to select & modify the digits.
- ENTER** Press **ENTER** key to returns to next MENU.



Prog Level Alarms	Set Points & Hys
Prog Flow Alarms	Set Points & Hys
Prog Level Alarms	Set Points & Hys
HH SET : XXXXX X X mm	
Prog Level Alarms	Set Points & Hys
L SET : XXXXX X X mm	
Prog Level Alarms	Set Points & Hys
LL SET : XXXXX X X mm	
Prog Level Alarms	Set Points & Hys
L Hys : X X mm	

Menu 4 - Using this menu each relay can be configured either on one of the HH / H / L / LL level alarms or can be configured on latch mode by setting set & reset values in mm for Pumping in or Pumping out modes or ON - OFF Valve Operation. If the relay is configured on HH / H alarm, relay is energised in normal mode & de-energised whenever level is \geq HH / H set point (FSH operation). Hysteresis is applicable for relay pickup. If the relay is configured on L / LL alarm, relay is energised in normal mode & deenergised whenever level is \leq L / LL set point (FSL operation). Hysteresis is applicable for relay pickup.

If the relay is configured on latch mode & if Set value is $>$ Reset value then the relay is energised when Level is \geq Set value & de-energised when Level is \leq Reset value. If Set value is $<$ Reset value then the relay is eneraised when Level is \leq Set value & de-energised when Level \geq Reset value.

RELAY ASSIGNED TO ALARM

HH Alarm	H Alarm	RELAY OFF (FSH)
L Alarm	LL Alarm	RELAY ON
L Alarm	LL Alarm	RELAY OFF (FSL)



Press NEXT key to display Menu 5.



Press ENTER key to configure Relay 1 assigned to Alarm / Latch.



UP (INC) key is used to toggle the Alarm / Latch



Press ENTER key to select Relay 1 on alarm.
Use UP (INC) key to assign Relay1 on one of the four HH / H / L / LL level alarms.



Press ENTER key to select Relay 2 assigned to latch. Program the Set value in mm.
NEXT (SHIFT) key is used to select digit



UP (INC) / DN (DEC) key is used to modify the digit.



After set value is programmed you have to reset value. NEXT, INC & DEC keys are used to select & modify the digit.



Same logic is followed for remaining three Relays



Press ENTER key to returns to Run Mode

Menu 4 : For relay programming in FLOW controller and totalise.



Press NEXT key to display Menu 5.



Press ENTER key to configure Relay 1 assigned to Alarm / Latch.



UP (INC) key is used to toggle the Alarm / Latch



Press ENTER key to select Relay 1 on alarm.
Use UP (INC) key to assign Relay1 on one of the four HH / H / L / LL level alarms.



Press ENTER key to select Relay 2 assigned to latch. Program the Set value in mm.



NEXT (SHIFT) key is used to select digit



UP (INC) / DN (DEC) key is used to modify the digit.



Same logic is followed for remaining three Relays



Press ENTER key to returns to next menu.

Menu 5 - This is Calibration Menu. In this menu a SHORT link provided internally is used to enable / disable the calibration as a safety measure. If the switch is OFF (disabled) the display menu 5 indicates following message and after a few seconds the next menu will be displayed.

If the switch is ON (enabled) the display indicates following message and the calibration is continued.

R	e	l	i	a	y	P	r	g	?						
P	r	e	s	s	E	N	T	/	N	E	X	T			

R	e	l	i	a	y	1	o	n							
A	l	i	a	r	m										

R	e	l	i	a	y	1	o	n	A	i	a	r	m	H	H

R	e	l	i	a	y	2	o	n	L	a	t	c	h		
R	e	l	i	a	y	S	e	t	:	x	x	x	x	m	m

R	e	l	i	a	y	2	o	n	L	a	t	c	h			
R	e	l	i	a	y	R	e	s	e	t	:	x	x	x	m	m

R	e	l	i	a	y	1	o	n							
A	l	i	a	r	m										

R	e	l	i	a	y	1	o	n	A	i	a	r	m	H	H
R	e	l	i	a	y										

R	e	l	i	a	y	2	o	n	L	a	t	c	h		
T	o	t	F	l	o	w	:	x	x	x	x	L	t		

C	a	l		D	i	s	a	b	l	e	d
.

C	a	l	I	Z	e	r	o	S	p	a	n
P	r	e	s	s	E	N	T	.	t	o	s	e	t		

Press NEXT key to display MENU 6.

Press ENTER key to set the input to 4 mA or 1 V to calibrate zero and press enter key to set

Press ENTER key to set the input to 20 mA or 5V to calibrate span and press enter key

If ENTER key is pressed the display returns to next MENU.

Menu 6 - This menu is displayed only when Flow is selected

This menu is used to reset the Totalise Flow value

Press NEXT key to display MENU 7.

Press ENTER key to reset the totalised flow.

C	a	l		Z	e	r	o		x	x	x	x	x
P	r	e	s	S	p	a	n		x	x	x	x	x

C	a	l		S	p	a	n		x	x	x	x	x
P	r	e	s	E	N	T		t	o	s	e	t	

R	e	s	e	t		T	o	t	a	l	i	s	e	r
Y	.	E	n	t	e	r	,	N	.	N	e	x	e	t

Menu 7 - This menu is used to enter volume table.

Press NEXT key to display Menu 8.

Press ENTER key to enter strap level intervals.

NEXT (SHIFT) key is used to select digit

UP (INC) / DN (DEC) key is used to modify the digit.

Press ENTER key to enter Volume in Ltrs for any strap level

NEXT (SHIFT) key is used to select digit

UP (INC) / DN (DEC) key is used to modify the digit.

Mode key is used to Escape

Menu 8 - This menu is used to change the Pass word

Press SHIFT (NEXT) to display Menu 9

Press ENTER key to enter old password

Using combination of 7 key stroke, the password can be entered.

Incorrect password will discontinue change password and go to next menu.

Correct old password allow to change and enter new password.

V	o	l		S	t	r	a	p		E	n	t	?
P	r	e	s	E	N	T		N	E	X	T		

V	o	l		S	t	r	a	p		E	n	t	r	y
L	I	n	t	:	x	x	x	x	m	m				

S	t	r	a	p		L	:	x	x	x	x	m	m
V	o	l	u	m	e	x	x	x	x	L	t	r	

C	h	a	n	g	e		P	a	s	s	w	o	r	d
Y	_	E	n	t	e	r	,	N	_	N	e	x	t	

E	n	t		O	l	d		P	a	s	s	w	o	r	d
P	a	s	W	r	d	:	—	—	—	—	—	—	—	—	

E	n	t		N	e	w		P	a	s	s	w	o	r	d
P	a	s	W	r	d	:	—	—	—	—	—	—	—	—	

Menu 9 - This menu is sued to save programmed data in non-volatile memory. Each time any programmed parameter is modified this menu is required to be executed to retain the modified data.

S	a	v	e		P	r	g		D	a	t	a	?
P	r	e	s	s	E	N	T	/	N	E	X	T	

Press NEXT key to unsaved and return to Run Mode.

R	E	T	U	R	N	T	O	R	U	N			
---	---	---	---	---	---	---	---	---	---	---	--	--	--

Press ENTER key to SAVE and return to Run Mode.

R	E	T	U	R	N	T	O	R	U	N			
---	---	---	---	---	---	---	---	---	---	---	--	--	--

10 TROUBLE SHOOTING -

Switch on the Instrument

	Fault / Defect	Cause & Remedy
1	No Back lit & Message appears on Display	a Check mains & fuses.
2	No change in flow	a Check flow transmitter / 4 - 20 mA, 1 to 5 V DC b Check if programming is correct . c Check flow Range Value is properly programmed .
3	Alarms generation faulty	a Check flow Alarm Set points & Hysteresis programmed properly.
4	Relay operation faulty	a Check Relay Configuration is correct. b Relay is faulty c Fault is due to case 2 and or case 3
5	Volume reading faulty	a Check Volume strap entry is correct b Fault is due to case 2
6	Totalise Volume reading faulty	a Check flow unit b Fault is due to case 2 c Check totalise flow unit