



## Elscint Automation

W-191 Bhosari MIDC, Pune 411 026  
Tel.: 27122059 Fax :+91 -20-27122994  
E-mail: [sales@elscintautomation.com](mailto:sales@elscintautomation.com)  
Website: [www.elscintautomation.com](http://www.elscintautomation.com)

### **Spare Parts for Elscint Linear Vibrators:**

The list of main spare parts and the recommended stocking quantity is given below:

In order to guarantee a quick handling of your Spare Part Order, please state the Model Number and Part Name correctly

#### Ordering Information (Qty)

<b>LF Model</b>	<b>I</b>	<b>II</b>	<b>III</b>	<b>IV</b>
Coil (Qty. per Unit, recommended Spare Qty)	Elscint I (1,1)	Elscint II (1,1)	Elscint III (1,1)	Elscint IV (1,1)
Magnet (Qty. per Unit, recommended Spare Qty)	Elscint I (1,1)	Elscint II (1,1)	Elscint III (1,1)	Elscint IV (1,1)
Rubber Grommet (Qty. per Unit, recommended Spare Qty)	Elscint I (4,2)	Elscint II (4,2)	N.A.	Elscint IV (4,2)
Springs (Qty. per Unit, recommended Spare Qty)	Elscint I (4,4)	Elscint II (4,4)	Elscint III (2,2)	Elscint IV (2,2)

